



Product Information


[Baja Web](#) > [Product Information](#) > [Parts Lists](#) > [GOKART](#) > BR250 Howhit Baja Reaction 250cc Go Kart (VIN PREFIX L6K)

BR250 Howhit Baja Reaction 250cc Go Kart (VIN PREFIX L6K)

BR250 Howhit Baja Reaction 250cc Go Kart (VIN PREFIX L6K)




Frame [Image]

**Frame**

Item No	Part Number	Description	Qty
	DN150-815	KEYS (1 SET)	1
	BR150S-554	HEAD LIGHT BULB	2
001	BR250-561	CABLE, PARKING BRAKE	1
001	BR250-601	CABLE, PARKING BRAKE	1
002	BR250-600	CABLE, REVERSE	1
002	BR250-602	CABLE, REVERSE	1
003	BR150S-102	ENGINE STOP BUTTON	1
004	BR150S-103	IGNITION START SWITCH	1
005	BR150S-535	REAR CARGO RACK RED	1
006	BR150S-105	TAIL LAMP	1
007	BR150S-106	HEADLIGHT SET	1
008	BR150S-107	WASHER F6(GB93)	6
009	BR150S-108	BOLT, M6X12(GB70)	6
010	BR250-100	FRAME	1
011	BR250-101	BACK SUPPORT BAR	2
012	BR150S-111	BOLT M8 X40(GB5783)	2
013	BR150S-112	NUT LOCKING FLANGE M8(GB6187)	2
014	BR150S-113	NUT M10-1.25X10, FLANGE SELF LOCK	4
015	BR150S-114	BOLT M10X1.25X25(GB5786)	4
016	BR250-102	DASHBOARD	1
017	BR250-103	WATER TEMPERATURE INDICATOR	1
018	BR250-104	LIGHT SWITCH	1
019	BR250-105	BOLT, M6X16	4
020	BR250-106	BOLT CAP	4


Brushguards [Image]



Brushguards

Item No	Part Number	Description	Qty
	BR250-158	PADDING AND WRAPS FOR FRAME	1
001	BR150S-539	GUARD BLACK	2
002	BR150S-538	FRAME CROSS MEMBER BAR BLACK	1
003	BR150S-540	RR .FRAME CROSS MEMBER BAR BLACK	1
004	BR150S-541	GUARD SIDE RAIL BLACK	2
005	BR150S-119	TUBE COLLAR F32	8
006	BR150S-120	WASHER M8X14X2, SPRING	8
007	BR150S-121	WASHER SPHERICAL M8-32	20
008	BR150S-122	BOLT M8 X 60 F8 (GB5782)	8
009	BR150S-552	PADDING FRAME BLACK	2
010	BR150S-124	NUT M8 (GB6187)	6
011	BR150S-125	BOLT M8 X 55 (GB5782)	6

Swing Arm [Image]




Swing Arm

Item No	Part Number	Description	Qty
001	BR250-107	NUT, M14X1.5	1
002	BR250-108	WASHER, 14	1
003	BR250-109	NUT, M14X1.5	2
004	BR250-110	CHAIN ADJUSTER	1
005	BR250-111	BOLT, M12X1.25X105	1
006	BR250-112	NUT, M12X1.25	3
007	BR250-113	BUFFER RUBBER	4
008	BR250-114	SHAFT BUSHING	1
008	BR250-603	BOLT, M12X1.25X70	1
009	BR250-115	RR. PLATE	1
010	BR250-116	CAP, OVERFLOW TANK	1
011	BR250-117	OVERFLOW TANK	1
012	BR250-118	NUT, M10X1.25	8
013	BR250-119	BOLT, M10X1.25X45	2
014	BR250-120	REAR SHOCK	2
015	BR250-121	BOLT, M10X1.25X40	2
016	BR250-122	NUT, M8	3
016	BR250-604	NUT M8	6
017	BR250-123	RUBBER BUSHING	3
017	BR250-605	BOLT, M8X45	2
018	BR250-124	BUSHING	3
018	BR250-606	BOLT, M8X16	2
019	BR250-125	WASHER 8	3
019	BR250-607	BOLT, M8X35	2
020	BR250-126	BOLT, M8X30	3
020	BR250-608	RADIATOR STAND	2
021	BR250-127	BOLT, M12X1.25X60	2

022	BR250-128	BATTERY COVER	1
023	90-01-9002	BATTERY (ETX9)	1
024	BR250-130	BOLT, M10X1.25X72	4
025	BR250-131	SMALL BUFFER RUBBER	4
026	BR250-132	COVER, ELECTRIC BOX	1
027	BR250-133	SCREW, M6X60	2
028	BR250-134	WATER PROOF PLUG	2
029	BR250-135	REAR SWING ARM	1
029	BR250-609	REAR SWINGARM NEW	1
030	BR250-136	BATTERY STRAP	1
031	BR250-137	RUBBER PAD, BATTERY	1
032	BR250-138	SMALL SWINGARM	1
033	BR250-139	NUT, M6	2
034	BR250-610	REAR ENGINE BRACKET BUSHING	1

Seat [Image]




Seat

Item No	Part Number	Description	Qty
001	BR250-140	HEADREST	2
002	BR250-141	SEAT, PASSENGER	1
003	BR250-142	SEAT, DRIVER	1
004	BR150S-170	SEAT BOLT M8X45(GB37)	2
005	BR150S-171	NUT M8 GB6187	6
006	BR150S-172	FUEL TANK CAP	1
007	BR150S-173	FUEL TANK	1
008	BR150S-174	BOLT, M8X45(GB5782)	4
009	BR150S-175	BOLT M10X1.25X25 (GB5786)	1
010	BR150S-176	RUBBER MOUNT	4
011	BR150S-177	WASHER M8X15X1.50, PLATE	4
012	BR150S-221	WASHER M12X24X2, PLATE	2
013	BR150S-179	FUEL VALVE	2
014	BR150S-208	BOLT M8X60 M8X55(GB5782)	2
015	BR150S-181	TUBE #1	1
016	BR150S-182	TUBE CLIP #2	4
017	BR150S-183	FUEL FILTER	1
019	BR150S-209	SPRING WASHER F8(GB93)	2
020	BR150S-186	SEAT BELT BOLT M12X30	2

021	BR150S-187	WASHER F12(GB97.1)	2
022	BR150S-188	NUT, M12(GB6171)	2
023	BR150S-189	SAFETY BELT	2
024	BR150S-190	BOLT M10X1.25X20 (GB5786)	2
025	BR150S-191	WASHER F10(GB97.1)	3
026	BR150S-192	NUT M10-1.25X10, FLANGE SELF LOCK	3
027	BR150S-212	SPRING WASHERF12(GB93)	2

Pedals [Image]




Pedals

Item No	Part Number	Description	Qty
	BR150S-625	BRAKE PEDAL, BLACK	1
	BR150S-626	GAS PEDAL, BLACK	1
001	BR150S-222	BRAKE PEDAL, RED	1
002	BR150S-223	PEDAL BUSH	4
003	BR150S-224	SPRING WASHER, F8(GB93)	2
004	BR150S-225	BOLT, M8X15(GB5783)	2
005	BR150S-226	WASHER, F12(GB97.1)	1
006	BR150S-227	COTTER PIN, 2X20(GB91)	3
007	BR150S-228	AXIS PIN, 6X16(GB882)	3
008	BR150S-229	U-JOINT	3
009	BR150S-230	HEX NUT M8(GB6170)	3
010	BR150S-231	LOCKING NUT, M8(GB6187)	4
011	BR150S-232	REAR BRAKE TENSION ROD	1
012	BR150S-233	REAR BRAKE RETURN SPRING	1
013	BR150S-234	BRAKE ARM	1
014	BR150S-235	COTTER PIN 2.5X35(GB91)	1
015	BR150S-236	GAS PEDAL, RED	1
016	BR250-143	CABLE, THROTTLE	1
017	BR150S-238	THROTTLE RETURN SPRING	1

018	BR150S-239	HAND BRAKE BAR COMP.	1
019	BR150S-240	U-JOINER #2	1
020	BR150S-241	BRAKE PEDAL COVER	2
021	BR150S-242	WASHER F8(GB97.1)	2
022	BR150S-243	FR. BRAKE CALIPER.L	1
023	BR150S-244	OIL PIPE#1	1
023	BR250-611	OIL PIPE#1	1
024	BR150S-245	FR. BRAKE CALIPER.R	1
025	BR150S-246	MASTER CYLINDER	1
026	BR250-144	OIL PIPE#2	1
027	BR250-145	RR. BRAKE CALIPER ASSY. W/BACKET	1
028	BR150S-249	NUT, M8(GB6187)	2
029	BR150S-250	SPINDLE PIN	1
030	BR150S-251	BOLT, M8X20(GB5783)	2
031	BR150S-252	REVERSE BAR COMP.	1
032	BR150S-253	FR. BRAKE PADS, FR. BRAKE PUMP	2
033	BR250-146	PADS, REAR BRAKE	1
034	BR150S-255	REVERSE LEVER COVER	2
035	BR150S-256	WASHER, F6(GB97.1)	3
036	BR150S-257	BOLT M8-1.25X30, FLANGE (FT)	2
037	BR150S-258	THROTTLE PEDAL COVER	1

Steering [Image]




Steering

Item No	Part Number	Description	Qty
	BR150S-627	STEERING FLANGE BRACKET, BLACK	1
001	BR150S-259	STEERING WHEEL CAP	1
002	BR150S-260	BOLT: M6X12(GB5783)	3
003	BR150S-261	LOCK WASHER F6(GB93)	3
004	BR150S-262	STEERING WHEEL	1

005	BR150S-263	STEERING WHEEL FLANGE	1
006	BR150S-264	BOLT: M8X25(GB5783)	4
007	BR150S-265	STEERING FLANGE BRACKET	1
008	BR150S-266	NUT M8(GB6187)	4
009	BR150S-267	STEERING FLANGE BRACKET, RED	1
010	BR150S-268	STEERING AXLE CAP	2
011	BR150S-269	ELASTIC RING F20(GB894)	1
012	BR150S-270	BOLT, M8X25(GB5783)	2
013	BR150S-271	WASHER, F8	2
014	BR150S-272	UNIVERSAL JOINT	1
015	BR150S-273	TIE ROD CONNECTOR RACK END	2
016	BR150S-274	NUT M12-1.25X11, HEX	2
017	BR150S-275	BOOT	2
018	BR150S-276	TIE ROD	2
019	BR150S-277	ROD END (24X10MM / 47X12MM)	2
020	BR150S-278	NUT M16 X 1.5(GB810)	2
021	BR150S-279	RACK AND PINION ASSEMBLY	1
022	BR150S-280	BOLT, M8X60(GB5782)	2
023	BR150S-281	NUT M8-1.25X9, FLANGE SELF LOCK	2

Rear Axle [Image]




Rear Axle

Item No	Part Number	Description	Qty
	BR150S-300	REAR RIM BLACK	2
001	BR150S-282	CAP, HUB	2
002	BR150S-283	PIN SPECIAL3X40(GB91)	2
003	BR150S-284	NUT M16-1.5X17, HEX CASTLE	2
004	BR150S-285	WASHER F16	2
005	BR150S-286	DUST COVER	2
006	BR150S-287	NUT FLANGE, M10X1.25(GB6187)	8

008	BR150S-289	HUB, REAR WHEEL	2
009	BR150S-290	WHEEL HUB STUDS(GB5782)	8
010	BR150S-291	BOLT M8X60	6
011	BR150S-292	OIL SEAL30X55X12(GB5782)	1
012	BR150S-293	BEARING 6006	2
013	BR150S-294	BEARING BASE	2
014	BR150S-295	NUT M8(GB6170)	6
015	BR150S-296	BOLT HHFS M8 X 25(GB5787)	8
016	BR250-148	SPROCKET, DRIVEN 33	1
017	BR250-149	AXLE	1
017	BR250-612	AXLE NEW	1
018	BR250-150	BRAKE DISC	1
019	BR150S-544	REAR RIM SILVER	2
020	BR150S-301	REAR TIRE 22X10-10	2
022	BR150S-303	WASHER F8 GB93	6
023	BR250-153	DRIVE CHAIN 50	1
024	BR150S-305	NUT M8(GB6187)	8
025	BR150S-306	OIL SEAL30X56X12(GB5782)	1

Front Suspension [Image]




Front Suspension

Item No	Part Number	Description	Qty
	BR150S-324	SPINDLE FR. RH	1
	BR150S-326	A-ARM DOWN RH	1
	BR150S-328	A-ARM UPPER RH	1
001	BR150S-307	CAP, HUB	2
002	BR150S-308	PIN SPLIT 2.5X35 (GB91)	2
003	BR150S-309	NUT CASTLE M14X1.5 (GB9459)	2
004	BR150S-310	WASHER F10 (GB96)	2
005	BR150S-311	BUSHING BRASS 27X5X8	2

006	BR150S-312	BEARING SEAL 27X42X7	2
007	BR150S-313	BEARING (GB6203)	2
008	BR150S-314	NUT M10(GB6187)	8
010	BR150S-316	WHEEL HUB	2
011	BR150S-317	TYRE BOLT,M10X1.25X35	8
012	BR150S-318	BRAKE DISK	2
013	BR150S-319	BOLT M6X16 GB5783	12
014	BR150S-320	BEARING(GB6204)	2
015	BR150S-321	BEARING SEAL 25X47X7	2
017	BR150S-323	SPINDLE FR. LH	1
018	BR150S-325	A-ARM DOWN LH	1
019	BR150S-327	A-ARM UPPER LH	1
020	BR150S-329	BOLT, M10X1.25X170(GB5787)	4
021	BR150S-330	NYLON COLLAR	8
022	BR150S-331	BOLT ,M8X16,FLANGE	4
023	BR150S-332	SPRING WASHER F8 (GB93)	4
024	BR150S-333	BUSHING	8
025	BR150S-334	BOLT M10X1.25X45	2
026	BR150S-335	NUT M10-1.25X10, FLANGE SELF LOCK	4
027	BR150S-336	COTTER PIN 2.5X30	2
028	BR250-155	SHOCK FR.(Red buggy)	2
028	BR250-156	SHOCK FR.(Black buggy)	2
029	BR150S-338	NUT, M10X.125(GB6187)	4
031	BR150S-340	FRONT TIRE 19X7-8	2
032	BR150S-545	FRONT RIM SILVER	2
032	BR150S-341	FRONT RIM BLACK	2
033	BR150S-342	CASTLE NUT, M12(GB9459)	2
034	BR150S-343	SPRING WASHER, M12(GB93)	2
035	BR150S-344	BOLT M10-1.25X40, HEX (PT)	2
036	BR150S-624	A-ARM BUSHING	1

Engine [Image]






Engine

Item No	Picture	Part Number	Description	Qty
001		BR250-465	ENGINE (250CC GO KART)	1
002		BR250-160	NUT	1
003		BR250-161	BOLT	1
004		BR250-162	AIR CLEANER	1
005		BR250-163	CLAMP, AIR BOX	2
006		BR250-164	HOSE, AIR BOX	1
008		BR250-166	RELAY, STARTER	1
010		BR250-168	CLAMP, CARBURETOR	1
011		BR250-169	CLAMP, LH COVER	1
013		BR250-171	CDI	1
014		BR250-172	BOLT M6X20	1
015		BR250-173	NUT M6	3
016		BR250-174	IGNITION COIL	1
017		BR250-175	BOLT M6X30	2
018		BR250-176	RECTIFIER	1
019		BR250-177	NUT M8	2
020		BR250-178	EXHAUST	1
020		BR250-614	MUFFLER NEW	1
021		BR250-179	SELF-LOCK NUT M8	8
021		BR250-615	FLANGE NUT	3
022		BR250-180	SELF-LOCK NUT M12X1.25	1
022		BR250-616	BOLT, M6X20	7
023		BR250-181	INSTALLATION PLATE, MUFFLER	2
023		BR250-617	WASHER 5	3
024		BR250-182	RUBBER WASHER, MUFFLER	4
024		BR250-618	WASHER 6	1
025		BR250-183	INSTALLATION COLLAR, MUFFLER	2

025		BR250-619	BOLT, M5X20	1
026		BR250-184	RR. BUSHING, ENGINE	1
026		BR250-620	RUBBER BUSHING	1
027		BR250-185	BOLT, M8X70	2
027		BR250-621	TEMPERATURE SWTICH NEW	1
028		BR250-186	COLLAR, CHAIN GUARD	1
029		BR250-187	BOLT, M12X1.25X70	1
030		BR250-188	BOLT, M8X140	1
030		BR250-622	BOLT, M8	1
031		BR250-189	BOLT, M6X12	2
032		BR250-190	SPRING WASHER 6	2
033		BR250-191	WASHER 6	2
034		BR250-192	CHAIN GUARD	1
035		BR250-193	BRACKET	1
036		BR250-194	COLLAR, REVERSE	1
037		BR250-195	REVERSE ASSEMBLY	1
038		BR250-196	WASHER, REVERSE SHAFT	1
039		BR250-197	NUT, M12X1.25	1
040		BR250-198	COTTER PIN 3.2X22	1
041		BR250-199	SCREW, M5X35	2
042		BR250-200	SPRING WASHER 5	3
043		BR250-201	COLLAR	1
044		BR250-202	BOLT, M8X40	1
045		BR250-203	SPRING WASHER, 8	2
046		BR250-204	BOLT, M8X20	1
047		BR250-205	BOLT, M8X30	1
048		BR250-206	BOLT, M10X1.25X30	2
049		BR250-207	SPRING WASHER 10	2
050		BR250-208	WASHER 10	2
051		BR250-209	COVER, SMALL	1
052		BR250-210	COVER, LARGE	1
053	Pic	BR250-211	WATER PIPE (HOSE TO RADIATOR CAP)	1
053		BR250-623	WATER PIPE NEW	1
054		BR250-212	CLAMP 12	2
055		BR250-213	RADIATOR	1
055		BR250-624	RADIATOR NEW	1
056		BR250-214	CAP, RADIATOR	1
057		BR250-215	BOLT	4
058		BR250-216	ELECTRIC FAN	1
058		BR250-625	ELECTRIC FAN NEW	1
059		BR250-217	BRACKET, RADIATOR	1
060		BR250-218	BOLT M6X40	4
061		BR250-219	SPRING WASHER 4	4
061		BR250-626	NUT, M12X1.25	1
062		BR250-220	WASHER 4	4
062		BR250-627	MAIN WIRING HARNESS	1
063		BR250-221	TUBE CLAMP 32	2
064	Pic	BR250-222	DRAIN PIPE (UPPER HOSE)	1
064		BR250-628	DRAIN PIPE NEW	1
065	Pic	BR250-223	HOSE, RADIATOR (LOWER HOSE)	1
065		BR250-629	FILL PIPE NEW	1
066		BR250-224	TUBE CLAMP 27	2
066		BR250-630	WATER PIPE	1

067	BR250-225	BOLT M8X50	1
067	BR250-631	CIRCULATION PIPE	1
068	BR250-226	WASHER 8	1
068	BR250-632	CIRCULATION PIPE CLAMP	1
069	BR250-227	RUBBER WASHER	1
070	BR250-228	BUSHING, WIND SCREEN	1
071	BR250-229	STAND, WIND SCREEN	1
072	BR250-230	BOLT M8X20	1
073	BR250-231	WIND SCREEN	1
074	BR250-232	HARNESS, SECONDARY WIRING	1
075	BR250-233	HARNESS, MAIN WIRING	1
076	BR250-234	EYE BOLT	1
077	BR250-235	NUT M12X1.25	1
078	BR250-236	BOLT M5X20	1
079	BR250-237	RUBBER BUSHING	1
080	BR250-238	BOLT M6X20	3
081	BR250-239	WASHER 6	3
082	BR250-240	WASHER 5	1
083	BR250-241	SWITCH, TEMPERATURE	1
084	BR250-242	GASKET, MUFFLER	1
085	BR250-243	NUT M4	4

Crankcase [Image]




Crankcase

Item No	Part Number	Description	Qty
001	BR250-244	CRANKCASE, RIGHT	1
002	BR250-245	OUTER BUSH. FR. SUSPENSION	2
003	BR250-246	O-RING15.8X2.4	4
004	BR250-247	INNER BUSH USH.FR. SUSPENSION	2
005	BR250-248	O- RING 7.5X1.5	1

006	BR250-249	GASKET, CRANKCASE	1
007	BR250-250	CRANKCASE, LEFT	1
009	BR250-251	INNER MACHINE OIL PIPE COMP	1
010	BR250-252	INNER MACHINE OIL PIPE SEALING RING	2
011	BR250-253	HEAT INSULATION	1
012	BR250-254	STUD BOLT B	1
013	BR250-255	STUD BOLT A	3
014	BR250-256	BEARING	1
016	BR250-257	OIL SEAL	1
017	BR250-258	CRANK OIL SEAL	1
018	BR250-259	NUT M8	1
019	BR250-260	BOLT M6?12	1
020	BR250-261	DOWEL PIN	2
021	BR250-262	BOLT M6?60	5
022	BR250-263	BOLT M6?70	3
023	BR250-264	BOLT M6?125	1
024	BR250-265	BEARING	1
025	BR250-266	OIL SEAL	1
030	BR250-267	NEEDLE BEARING	1

Left Crankcase Cover [Image]




Left Crankcase Cover

Item No	Part Number	Description	Qty
001	BR250-268	COVER, LEFT CRANKCASE	1
002	BR250-269	WASHER CASE, L. COVER	1
003	BR250-270	VENT GUIDE PLATE	1
004	BR250-271	BOLT	2
005	BR250-272	RUBBER CUSHION	2
006	BR250-273	DOWEL PIN	2
007	BR250-274	CAP BOLT	1

008	BR250-275	CROSS RECESS PAN HEAD SCREW	4
009	BR250-276	FIXED CABLE CLIP COMP.	1
010	BR250-277	BOLT M6*16	1
011	BR250-278	DUSTPROOF BAR(A) INSIDE OF L.COVER.CASE	1
012	BR250-279	DUSTPROOF BAR(B) INSIDE OF L.COVER.CASE	1
013	BR250-280	WASHER, SEALING(INSIDE OF L.COVER.CASE)	1

Vent [Image]




Vent

Item No	Part Number	Description	Qty
001	BR250-281	VENTILATE HOSE	1
002	BR250-282	VENTILATE HOSE	1
003	BR250-283	VENTILATE HOSE	1
004	BR250-284	HOSE FIXED CARD	1
005	BR250-285	COVER, RIGHT CRANKCASE	1
006	BR250-286	BAFFLE	1
007	BR250-287	GASKET, RIGHT CRANKCASE COVER	1
008	BR250-288	BOLT, OIL SCREEN COVER	1
009	BR250-289	OIL SCREEN	1
010	BR250-290	SPRING, OIL SCREEN	1
011	BR250-291	GAUGE OIL LEVEL	1
012	BR250-292	EXHAUST GAS BRANCH JOINT	1
013	BR250-293	BOLT	1
014	BR250-294	BOLTM6*80	1
015	BR250-295	O-RING 30X3.55	1
016	BR250-296	O RING	1
017	BR250-297	O-RING 18X3.55	1
018	BR250-298	OIL DRAINING BOLT M12*1.5	1
019	BR250-299	WASHER 12	1
020	BR250-300	DOWEL PIN	2

021	BR250-301	PIPE CLIP	2
022	BR250-302	PIPE CLIP	4
023	BR250-303	VENTILATE PIPE TIE-IN	1
024	BR250-304	EXCURRENT SIPHON TIE-IN	1
025	BR250-305	BOLT M6?40	3
026	BR250-306	VENTILATE RUBBER PIPE JACKET	1
027	BR250-307	BOLT M6?28	1
028	BR250-308	BOLT M6?70	3
029	BR250-309	O-RING 15.8X2.4	1

Cylinder Head Cover [Image]




Cylinder Head Cover

Item No	Part Number	Description	Qty
001	BR250-310	VITTA CLIP	1
002	BR250-311	COVER, CYLINDER HEAD	1
003	BR250-312	BAFFLE	1
004	BR250-313	GASKET, CYLINDER HEAD COVER	1
005	BR250-314	ROCKER SHAFT COMP, VALUE IN	1
006	BR250-315	ROCKER SHAFT COMP, VALUE OUT	1
007	BR250-316	OUTER MACHINE OIL PIPE COMP	1
008	BR250-317	OIL PIPE RUBBER RING	1
009	BR250-318	OIL PIPE STAND	1
010	BR250-319	SHOCK ABSORPTION ADHESIVE TAPEY	1
011	BR250-320	GENERAL BOLT A M8X25	1
012	BR250-321	GENERAL BOLT B M12X12.5	1
013	BR250-322	GENERAL BOLT C M8X25	1
014	BR250-323	UPPER CAP	1
015	BR250-324	WASHER 8	3
016	BR250-325	WASHER	1
017	BR250-326	WASHER 12	2

018	BR250-327	O RING	1
019	BR250-328	O RING	2
020	BR250-329	BOLT M5X16	1
021	BR250-330	WASHER	2
022	BR250-331	DOWEL PIN	2
023	BR250-332	BOLT M6?12	3
024	BR250-333	BOLT M6?25	1
025	BR250-334	BOLT M6?50	3
026	BR250-335	BOLT M6?55	1
027	BR250-336	SHOCK ABSORPTION BUSH	1
029	BR250-337	AIR FILTER RIGID BEARING	1
030	BR250-338	SEPARATOR KIT (INSIDE OF CYLINDER HEAD C	1

Cylinder Head [Image]




Cylinder Head

Item No	Part Number	Description	Qty
001	BR250-339	CYLINDER HEAD	1
002	BR250-340	VENT-PIPE FLANGE COMP	1
003	BR250-341	CAMSHAFT FIXED STAND	1
004	BR250-342	NUT	2
005	BR250-343	GASKET, CYLINDER HEAD	1
006	BR250-344	INTAKE PIPE	1
007	BR250-345	CLIP COMP	1
008	BR250-346	THERMOSTAT	1
009	BR250-347	CONSTANT TEMPERATURE IMPLEMENT COMP	1
010	BR250-348	CARBURETOR COOLING RUBBER PIPE I	1
011	BR250-349	COVER, CONSTANT TEMPERATURE IMPLEMENT	1
012	BR250-350	SPARK PLUG	1
013	BR250-351	BOLT M6X25	2
014	BR250-352	VENT-PIPE SEALING BUSH	1

015	BR250-353	WATER TEMPERATURE SENSOR	1
016	BR250-354	BOLT-M6?18-D.CR	2
017	BR250-355	STUD BOLT	2
018	BR250-356	WASHER	4
019	BR250-357	NUT	4
020	BR250-358	O-RING 14.8X1.9	1
022	BR250-359	BOLT M6?22	2
023	BR250-360	DOWEL PIN	2
024	BR250-361	PIPE CLIP	2
025	BR250-362	BOLT M6?16	2
026	BR250-363	BOLT M6?18	1
027	BR250-364	CARBURETOR HOSE	1
028	BR250-365	WASHER	1
029	BR250-366	BOLT M12?1	1


Valves [Image]



Valves

Item No	Part Number	Description	Qty
001	BR250-367	OIL SEAL, VALVE	2
002	BR250-368	CAMSHAFT ASSEMBLY	1
003	BR250-369	ROCKER VALVE	2
004	BR250-370	INTAKE VALVE	1
005	BR250-371	EXHAUST VALVE	1
006	BR250-372	SPRING, OUTER VALVE	2
007	BR250-373	SPRING, INNER VALVE	2
008	BR250-374	SEAT VALVE SPRING UPPER	2
009	BR250-375	SEAT VALVE SPRING LOWER	2
010	BR250-376	COTTER VALVE	4


Cylinder [Image]



Cylinder

Item No	Part Number	Description	Qty
001	BR250-377	CYLINDER	1
002	BR250-378	GASKET, CYLINDER	1
003	BR250-379	TIGHTENER ASSEMBLY	1
006	BR250-380	GASKET, TENSIONER	1
007	BR250-381	WATER PIPE	1
008	BR250-382	WATER PIPE JACKET	1
009	BR250-383	CLIP B24	2
011	BR250-384	WASHER	1
012	BR250-385	DOWEL PIN	2
013	BR250-386	BOLT M6X18	2
014	BR250-387	BOLT M6X22	1


Timing Chain [Image]



Timing Chain

Item No	Part Number	Description	Qty
001	BR250-388	CHAIN, TIMING	1
002	BR250-389	TENSIONER CAM CHAIN	1
003	BR250-390	GUIDE CAM CHAIN	1
004	BR250-391	WASHER	1
005	BR250-392	HEXAGON HEAD BOLT M6X12	1


Magneto [Image]



Magneto

Item No	Part Number	Description	Qty
001	BR250-393	ONEWAY CLUTCH	1
004	BR250-394	FLYWHEEL	1
005	BR250-395	STATOR	1
006	BR250-396	BOLT M8X18	3
007	BR250-397	NUT M16?1	1
008	BR250-398	WASHER 16.3X30X2	1
009	BR250-399	BOLT M5?16	2
010	BR250-400	BOLT M6?30	3


Crankshaft [Image]



Crankshaft

Item No	Part Number	Description	Qty
001	BR250-401	CRANKSHAFT	1
002	BR250-402	PISTON RINGS	1
003	BR250-403	PISTON	1
004	BR250-404	PIN, PISTON	1
005	BR250-405	OIL DUCT TIE-IN	1
006	BR250-406	OIL DUCT TIE-IN SPRING	1
007	BR250-407	WOODRUFF KEY 25?14?4	1
008	BR250-408	CLIP, PISTON PIN	2
009	BR250-409	CYLINDER PIN	1


Drive Pulley [Image]



Drive Pulley

Item No	Part Number	Description	Qty
	BR250-410	CLUTCH, DRIVE	1


Driven Pulley [Image]



Driven Pulley

Item No	Part Number	Description	Qty
001	BR250-411	CLUTCH, DRIVEN	1
005	BR250-412	CLUTCH SHOES	3
007	BR250-413	BELT, DRIVE	1


Transmission [Image]



Transmission

Item No	Part Number	Description	Qty
001	BR250-414	VENT TUBE	1
002	BR250-415	COVER TRANSMISSION CASE	1
003	BR250-416	WASHER, TRANSMISSION CASE	1
004	BR250-417	TRANSMISSION MAIN SHAFT	1
005	BR250-418	SMALL SHAFT	1
006	BR250-419	MIDDER GEAR	1
007	BR250-420	TRANSMISSION SIDE SHAFT	1
008	BR250-421	END GEAR	1
009	BR250-422	BOLT M8?38	3
010	BR250-423	BOLT M8?28	2
011	BR250-424	WASHER 14	1
012	BR250-425	WASHER 14	1
013	BR250-426	WASHER 6	1
014	BR250-427	WASHER 10	1
015	BR250-428	BEARING 6304	1
016	BR250-429	BEARING 22?50?14	1
017	BR250-430	OIL SEAL FB22?35?5	1
018	BR250-431	DOWEL PIN	2
019	BR250-432	STOP RING24	1
020	BR250-433	BOLT	1
021	BR250-434	BOLT M6?32	2
022	BR250-435	BEARING	1


Oil Pump [Image]



Oil Pump

Item No	Part Number	Description	Qty
001	BR250-436	OIL PUMP	1
005	BR250-437	SPROCKET, OIL PUMP	1
006	BR250-438	CHAIN, OIL PUMP	1
009	BR250-439	OIL SEPARATOR UNDER	1
010	BR250-440	OIL SEPARATOR ABOVE	1
013	BR250-441	TIMMING DRIVER SPROCKET	1
014	BR250-442	BOLT M6X12	1
015	BR250-443	BOLT M6X28	2


Water Pump [Image]



Water Pump

Item No	Part Number	Description	Qty
001	BR250-444	WATER PUMP IMPELLER	1
002	BR250-445	WATER BACKFILL COMP.	1
003	BR250-446	COVER, WATER PUMP	1
004	BR250-447	GASKET, WATER PUMP COVER	1
005	BR250-448	SHAFT, WATER PUMP	1
006	BR250-449	BOLT M6X40	2
007	BR250-450	BOLT M6X25	2
008	BR250-451	CIRCLIP	1
009	BR250-452	WASHER 7.5X13X1.2	1
010	BR250-453	WASHER 6X12X1	1
011	BR250-454	BEARING 6800	2
012	BR250-455	OIL SEAL 10X20X5	1
013	BR250-456	DOWEL PIN	2


Starter Motor [Image]



Starter Motor

Item No	Part Number	Description	Qty
001	BR250-457	SHAFT, GEAR	1
002	BR250-458	GEAR, STARTER	1
003	BR250-459	SPROCKET, STARTER	1
004	BR250-460	FIXED PLATE	1
005	BR250-461	STARTER MOTOR	1
006	BR250-462	BOLT M6X22	2
007	BR250-463	BOLT M6X14	1

Carburetor [Image]



Carburetor

Item No	Part Number	Description	Qty
001	BR250-464	CARBURETOR	1